



Recall plate wiring
White – Recall side
Black – Center post
Grn/Red – Erase side

Memory Functions

Clear – Push “Erase” switch before each run. Now you are ready to record. After clearing memory, hitting recall will register something. Disregard, this is normal.

Recall – Push “Recall” to display highest RPM reached. This can be done at any time during or after a run. To clear for next segment push “Erase.”

Tach pointer may not rest on Zero when turned off. This is normal. When 12 volt power is applied tach will register correctly.

Cleaning

Lens is plastic and should only be cleaned with a mild soap and soft rag. Do not pressure wash tach.

Warranty

Product is warranted against defects of material and craftsmanship for a period of one year from original date of purchase. If a need arises, return product to the point of purchase with original invoice for proof of purchase date. The return will be inspected for possible repair or replacement if deemed to be defective. We will not warranty any product that has been misused, abused or installed incorrectly. This warranty does not include labor, personal injury or damage to other parts.

All forms of motor sports are dangerous and may cause bodily harm and even death. User assumes all risk and liability associated with the use of QuickCar Racing Products.